



English

1. Mount the wall bracket to the wall. The slots make it possible to adjust the mount in height at a later stage.
Attention!! Make sure that when mounting, the right notch (A) of the wall plate is placed above the centre of the projection facet (board).
2. Position the wall cap over the wall bracket. Do not fix the cap to the wall plate yet, to make sure that cables can be attached at a later stage.
3. Mount the projector to the bracket according to the image above. Use the five spacers, washers and bolts.
4. Loosen the four bolts of the clamping bracket (B) above the projector bracket a bit, and shove the bracket with the projector attached over the wall bracket. Determine the required distance of the projector to the wall and tighten the bolts of the clamping bracket to fixate the position of the projector.
5. Run the cables alongside the wall plate from the top- or bottom through the tube. Then lead the cables through the tube and wall cap up to the front and attach them to the projector.
6. Position the wall cap as close as possible against the wall and mount it on the top to the wall plate with two bolts.
7. By means of the two rotary knobs it is possible to precisely adjust the projection heading. By adjusting knob A, the projector could be tilted sideways. Knob B makes it possible to tilt the projector face up or down.
8. After the projector is adjusted the unit can be finished with a cap. Fasten the cap to the bracket with two bolts.

Nederlands

1. Monteer de wandbeugel aan de muur. De sleuven maken het mogelijk de beugel in een later stadium in hoogte bij te stellen.
Let op!! Zorg bij de montage dat de rechter inkeping (A) van de muurplaat boven het midden van het projectievlak(-bord) zit.
2. Schuif de muurkap over de wandbeugel. Monteer deze nog niet vast aan de muurplaat zodat de bekabeling in een later stadium aangebracht kan worden.
3. Monteer de projector aan de bracket volgens tekening. Gebruik hiervoor vijf afstandbussen, sluitringen en bouten.
4. Draai de vier boutjes van het beugeltje (B) bovenop de bracket iets los en schuif vervolgens de bracket met de projector over de wandbeugel. Bepaal de gewenste afstand van de projector tot de wand en draai de vier boutjes van het beugeltje vast zodat de positie van de projector gefixeerd wordt.
5. Steek de bekabeling bij de muurplaat vanaf boven- of onderzijde door de buis. Voer vervolgens de bekabeling door de buis en de muurkap naar voren en sluit de kabels aan op de projector.
6. Schuif de muurkap zo dicht mogelijk tegen de wand en monteer deze vervolgens aan de bovenzijde met twee bouten aan de muurplaat.
7. Door middel van twee draaiknoppen is het mogelijk de projectierichting nauwkeurig af te stellen. Door aan knop A te draaien kan de projector zijwaarts gekanteld worden. Knop B zorgt voor het voorover kantelen van de projector.
8. Nadat de projector is afgesteld kan het geheel afgewerkt worden met de afwerkkap. Zet de afwerkkap vast aan de bracket met behulp van twee bouten.